
Scalarider[®] QUICK GUIDE

This Quick Guide is not a substitute to the user manual and addresses only a limited scope of features and functions of your **scala rider G9x**. Use it to look up basic functions and commands while you are on the road without the user manual.

This Quick Guide can be printed and folded for easy reference while on the road, or it may be viewed directly on your smartphone or tablet.



1 GENERAL FUNCTIONS

Power ON / OFF	Press Of for 2 seconds • ON: 3 BLUE flashes + ascending tone • OFF: 3 RED flashes + decending tone
Volume	Tap ⊕ or ⊖ to adjust and set volume of current audio source
Mute	Tap 🔁 and 🗢 simultaneously
Battery level indicator	In Standby, press 🗣 for 2 seconds • Blue LED = Full charge • Purple LED = Half charge • Red LED = Almost empty
Hear Your Buddy Name	In Standby, tap 🕥 and 🕒 simultaneously
Paired Device Indication	In Standby, press \textcircled{O} and \textcircled{O} for 2 seconds If "One+8" Buddies are within range, purple LEDs flash for 2 seconds
Group Signal	Tap 🕥 twice
Enable / Disable Spoken Status Announcements	Press 🗢 and 🕥 for 2 seconds

² | SETTINGS MENU

Enter Menu	In Standby, press A and B for 2 seconds
Exit Menu	Press 🕑 for 2 seconds

³ MAIN UNIT LED INDICATION	
None	scala rider G9x is OFF
1 BLUE flash every 3 seconds	Standby mode – No active audio
2 BLUE flashes every 3 seconds	Active mode – Call in progress / music or other audio source is ON
1 RED flash every 3 seconds	Standby mode – Battery is low
2 RED flashes every 3 seconds	Active mode – Battery is low
Solid RED	Charging

4 VOICE CONNECT (VOX)		
VOX Sensitivity (Default: Medium)	Adjust via the Settings Menu or the <i>Cardo Community.</i> High: Use this setting if it is difficult to activate VOX Low: Use this setting if it is too easy to activate VOX	
VOX Operation Mode VOX can be set to activate the Voice Command (defail to start an Intercom Call via the Cardo Community		
Enable / Disable VOX (For Intercom calls only)	La Enablade Blue flach for 2 seconds	

5 VOICE COMMANDS

1. In Standby, tap 🕟 or speak any word loudly to activate VOX 2. Speak a Voice Command from the table below:

Current Mode	Desired Action	Say this:
Standby / FM / A2DP	"One+8" Intercom Call	< <buddy name="">></buddy>
/ AUX	Intercom call with A or B	"Call Intercom"
Standby	Start A2DP	"Music ON"
Standby	Turn on FM	"Radio ON"
	Turn off FM	"Radio OFF"
FM Radio	Next Station Preset	"Next Station"
	Previous Station Preset	"Previous Station"
	Next track	"Next track"
A2DP Music	Previous track	"Previous track"
	Stop / Pause A2DP	"Music OFF"

6 PAIRING BLUETOOTH DEVICES: MOBILE PHONE/GPS/A2DP MUSIC PLAYER Bluetooth Channel 1 pairing mode In Standby, press Tor 5 seconds

Bluetooth Channel 1 pairing mode	In Standby, press 🗢 for 5 seconds
Bluetooth Channel 2 pairing mode	In Standby, press 🗢 for 5 seconds

7 PHONE CALLS Answer a call Tap Or speak any word loudly to answer by VOX Remain silent for 15 seconds, or press for 2 seconds **Reject a call** Tap 👄 End a call Voice Dial* (if supported by Tap 🗢 and follow the prompt from the mobile mobile phone) **Redial*** Double-tap Double-tap (B) or tap (A) and (B) simultaneously Hot Dial** Set default mobile*** While on a phone call, press 🕀 for 5 seconds

 Change default mobile
 In Standby, press 🕒 and 🗢 for 5 seconds

 INTERCOM CONFERENCE MODE

 Add/Remove Channel "A"
 Tap 👁 while on a phone call

 Add/Remove Channel "B"
 Tap 👁 while on a phone call

*This feature is not available during intercom or mobile calls.

to/from a call

** Before using Hot-Dial, configure the number via the Cardo Community.

*** If 2 mobile phones are paired directly to your scala rider G9x, set one to use as default for outgoing calls.

Tap **B** while on a phone call

⁸ A2DP MUSIC	
Play	In standby, press \Lambda for 2 seconds or use Voice Command
Pause/Stop	Press 🚯 for 2 seconds or use Voice Command
Next Track	With music ON, press 🗣 for 2 seconds or use Voice Command
Previous Track*	With music ON, press 🗢 for 2 seconds or use Voice Command
Music Scan	With music ON, press 🔂 (scans up) or 🗢 (scans down) for 5 sec. The first few seconds of each audio track will be played.
Stop Scan	To stop the scan on the current track, say any word loudly into the microphone or tap
Music Sharing (via A2DP only)	
[SENDER] Start/Stop sharing your music	During A2DP music playback, press ③ for 2 seconds
[RECEIVER] Stop music sharing	Press 🕒 for 2 seconds

*With some phones you may need to repeat this action

۶ FM RADIO	
Radio On	In standby, press 🕒 for 2 seconds or use Voice Command
Radio Off	Press ③ for 2 seconds or use Voice Command
Next Station	With radio ON, tap 🕒 or use Voice Command
Previous Station	Use Voice Command
RDS ON/OFF (Default: Off)	With Radio ON, press 🗢 and 🗢 simultaneously for 2 seconds

10 INTERCOM

Note: *G9x PowerSet*[™] *units are already factory paired!*

Pairing	
Pairing with a "One+8" Intercom Buddy	 Via the Cardo Community Flash-Pairing In Standby, press for 5 secs. Purple LED = success
Pairing Intercom Channel A	 Flash-Pairing (tap A) In Standby, press A for 5 seconds – Rapid RED flashing
Pairing Intercom Channel B	 Flash-Pairing (tap 3) In Standby, press 3 for 5 seconds. – Rapid BLUE flashing
3-Way Intercom • Rider 1 and Rider 2 pair via "A" • Rider 1 and Rider 3 pair via "B"	
4-Way Intercom	 Rider 1 and Passenger 2 pair via "A" Rider 3 and Passenger 4 pair via "A" Passenger 2 and Passenger 4 pair via "B"

Calling "One+8" Intercom Buddies

Voice Connect (VOX)	Manual Mode
 a. Speak any word loudly into the microphone or tap . b. When you hear the Voice Command tone, say the name of the "One+8" Buddy 	 a. Press ♥ for 2 seconds b. Hear the names of all paired Buddies. c. Tap ♥ or speak any word loudly into the microphone when you hear the name. To cancel "One+8" Buddy List playback: Press ♥ for 2 seconds.

Calling Intercom Channels "A" and "B" (Two and Three-Way Calls)		
Voice Connect (VOX)	Manual Mode	
Speak any word loudly into	Use this to start an Intercom call with:	
the microphone. When you hear the Voice Command tone.	• Channel "A": Tap 🕢	
say "Call Intercom" to start an	• Channel "B": Tap 🚯	
intercom call with "A" and/or "B" (subject to who is present)	To end a call tap 🗛 or 🕃 again.	
VOX Intercom call with only "A" or "B" will end automatically after 30 seconds of silence.	If you are already in an Intercom call with "A" or "B", you can add another rider ("A" or "B") by tapping the other channel button, or another rider can join the intercom call in the same way.	

Three-Way Calls





Calling

- 1. Make sure all four units are in Standby.
- 2. Passenger 2 should tap 🕃 to call Passenger 4. Wait until audio is heard on both units.
- 3. Rider 1 should tap 🚯 to call Passenger 2.
- 4. Rider 3 should tap \Lambda to call Passenger 4.

11 | CLICK TO LINK ("CTL") CALLS

Start a CTL call request (search lasts up to 10 sec.)	Double-tap 🚯
End a <i>CTL</i> call / Cancel a <i>CTL</i> call request	Tap \Lambda or 🔊
Accept a <i>CTL</i> call	When hearing the <i>CTL</i> ringtone: Tap (A) or say any word loudly to answer by VOX
Reject a <i>CTL</i> call	While hearing the <i>CTL</i> ringtone: Remain silent until the ring tone stops or press A or B for 2 seconds
Enable / Disable CTL (Enabled by default)	Via the Settings Menu or Cardo Community

12 | TROUBLESHOOTING

Reboot	If your scala rider stops responding, reset it by turning it off and then on again (press 🗢 for 2 seconds).
Reset Pairing (Deletes all paired devices)	 In Standby, press or or for 5 secs until LED flashes RED/ BLUE. Press for 2 seconds until LED flashes 5 times in PURPLE.

The contents of this User Guide, including all text, illustrations and drawings are the exclusive intellectual property of Cardo Systems, Inc. (the "Company") and are protected by copyright laws. Any partial or total reproduction, translation and or dissemination, without the prior written authorization by the Company are strictly prohibited. Any rights not expressly granted herein are reserved.